Instructions for the water connection of Beer Marie

No	Picture	Description
1		A 1.1 I/min flow limiter is supplied separately with every Beer Marie and must only be used if the water pressure lies over 3 bar . Please follow the following steps to install the flow limiter.
2		Carefully remove the filter sieve with appropriate pliers.
3		Place the flow limiter as illustrated onto the filter sieve.
4		Put the filter sieve and flow limiter back with appropriate pliers.
5		Connect the water supply.